



Depth stop

Depth stop for all saw blades. For accurate working at depth. Effective protection for blade and workpiece.

Contents: 1 adapter for attachment to the machine. 1 depth stop, 1 depth-adjustable guide block.

Can only be used with (A)MM 500 / 700.

Product number: 3 21 27 069 01 0

Suitable for the following tools

- | | | |
|---|---|--|
| <ul style="list-style-type: none"> > Cordless MULTIMASTER AMM 500 Plus Top AS | <ul style="list-style-type: none"> > Cordless MULTIMASTER AMM 700 Max Top 4 Ah AS | <ul style="list-style-type: none"> nylon bag |
| <ul style="list-style-type: none"> > Cordless MULTIMASTER AMM 500 Plus AS | <ul style="list-style-type: none"> > Cordless MULTIMASTER AMM 700 Max Top AS | <ul style="list-style-type: none"> > Cordless MULTIMASTER AMM 500 PLUS 4 Ah with nylon bag |
| <ul style="list-style-type: none"> > Cordless MULTIMASTER AMM 700 Max AS | <ul style="list-style-type: none"> > Cordless MULTIMASTER AMM 500 AS 2 Ah with | <ul style="list-style-type: none"> > Cordless MULTIMASTER AMM 700 Max AS 4 Ah with nylon bag |