



Depth stop

Depth stop for all saw blades. For precise, deep work. Effective saw blade and workpiece protection. Contents: 1 adapter for attachment to the machine. 1 depth stop, 1 adjustable depth guide.

Only usable with (A)MM 500 / 700.

Product number: 3 21 27 069 01 0

Suitable for the following tools

- > MULTIMASTER MM 500 Plus Top
- > MULTIMASTER MM 500 Start Kit
- > Cordless MULTIMASTER AMM 700 AS 4 Ah with nylon bag
- > MULTIMASTER MM 500 Plus QuickStart
- > MULTIMASTER MM 300 Plus QuickStart